

Part #18-046 Radiator Brace Instructions

Remove the radiator shroud, then remove the bolt securing the plastic louver. NOTE-Front of Radiator Brace fits under plastic louver.

Position Radiator Brace into place and insert the supplied 16mm louver mounting bolt (with the 15mm washer) through the brace and thread it into the louver. Align the Radiator Brace's two remaining holes and tighten the louver mounting bolt. Install the shroud and tighten the shroud bolts.