

Part #18-772 Radiator Brace Instructions

Note-You will reuse the stock 6x16mm bolt that you remove from the shrouds lower, front mount hole.

Right-Remove the radiator shroud. Remove the louvers black push-in retainer. Position the Radiator Brace in place and line up the three mounting holes. Install a washer onto the stock 6x16mm bolt. From the outside of the Radiator Brace insert the 6x16mm bolt with washer into the upper, front mounting hole. On the backside, install a washer and a 6mm nut. Double check to insure all the mounting holes are aligned. Tighten this fastener. Position the shroud into place and install the 6x20mm bolt and the stock aluminum collar into the shroud's lower, front hole-leaving it loose for now. Reinstall the three remaining stock bolts and collars. Tighten all four bolts to the manufacturers recommended specifications.

Left-Repeat above.