

## **18-197/18-B197 Radiator Braces Instructions**

**Left-** Remove the left radiator shroud and the bolt securing the stock plastic louver at its upper mount point.

Locate the left side Radiator Brace and hold it in place. Insert one supplied 6mm bolt into a washer and then through the upper Radiator Brace mount hole and into the stock plastic louver. Tighten this bolt only after you have lined up the two remaining mounting holes in the Radiator Brace with their respective locations. Position the radiator shroud back in place and install the stock bolts. Tighten all four bolts to the O.E.M. recommended specifications

**Right-** Remove the right radiator shroud and the bolt securing the stock plastic louver at its upper mount point.

Locate the right side Radiator Brace and hold it in place. Insert one supplied 6mm bolt into a washer and then through the upper Radiator Brace mount hole and into the stock plastic louver. Tighten this bolt only after you have lined up the two remaining mounting holes in the Radiator Brace with their respective locations. Position the radiator shroud back in place and install the stock bolts. Tighten all four bolts to the O.E.M. recommended specifications