

## **18-267/18-B267 Radiator Brace Instructions**

Remove seat from bike for shroud bolt access.

**Right-**Remove the radiator shroud from bike.

Install the two rubber isolator grommets in the 1/2 inch holes of the Radiator Brace. Using the two supplied Allen head bolts, attach the formed bracket to the backside of the Radiator Brace.

Remove the front bolt securing the 'frame to head motor mount bracket. Place the Radiator Brace into position. Use the stock motor mount bolt to secure the formed bracket/Radiator Brace to the frame (finger tight for now).

Install the radiator shroud using a supplied 6x16 bolt and washer for the upper and lower shroud bolts. Install the two remaining stock shroud bolts. Tighten all four shroud bolts to the O.E.M. spec. Tighten the two Allen head bolts to 6-9ft/lbs and then the motor mount bolt to the O.E.M. spec.

**Left-**Same as Right.

Install seat back on bike.