

Part #10-108, 10-109 Skid Plate Instructions

IMPORTANT-use some form of thread-locking compound. #242 blue Loc-tite is recommended.

Install (1) of the U-shaped brackets over the frame rail near the oil drain bolt, this will be the rear mount. Start two screws into the rear bracket, leave loose for now. Position front bracket over frame tube and install two screws. Adjust the Skid Plate into the correct position and tighten all four screws