

## **Part # 10-206**

### **Skid Plate Instructions**

USE SOME FORM OF THREAD LOCKING COMPOUND ON THE FASTENERS. #242 BLUE LOC-TITE IS RECOMMENDED.

*Note-The rear brackets can be identified as being larger than the front brackets.*

Remove the plastic ties that secure the two vent hoses to the frame rails.

Place both rear brackets on the skid plate and thread the bolts into the brackets 4-5 turns.

Position the skid plate into place by mating the rear brackets to the frame's crossmember and the skid plate up against the frame rails.

Place one of the front brackets into position and thread the bolt into the bracket 4-5 turns.

Repeat for the other front bracket.

Confirm the rear brackets are seated against the frame's crossmember and the skid plate is centered on the frame rails.

Tighten both rear fasteners to 9-12 ft/lbs.

Push up on the skid plate so it mates up against frame rails and tighten front brackets to 9-12lbs.

Reinstall the plastic ties that secure the vent hoses.